



Woodcert Non Headed Type E

| Part No. | Thread | L | Pilot Hole | E | E1 | H |
|----------|--------|----|-------------|------|------|-----|
| M410 | M4 | 10 | 5.7 / 6.0 | 5.5 | 7.3 | 4.0 |
| M513 | M5 | 13 | 7.7 / 8.0 | 6.7 | 10.9 | 5.0 |
| M610 | M6 | 10 | 8.7 / 9.0 | 7.5 | 12.0 | 6.0 |
| M613 | M6 | 13 | 8.7 / 9.0 | 7.5 | 11.5 | 6.0 |
| M620 | M6 | 20 | 8.7 / 9.0 | 7.5 | 11.7 | 6.0 |
| M813 | M8 | 13 | 11.2 / 11.5 | 9.5 | 14.2 | 8.0 |
| M820 | M8 | 20 | 11.2 / 11.5 | 9.5 | 14.3 | 8.0 |
| M825 | M8 | 25 | 11.2 / 11.5 | 10.5 | 14.3 | 8.0 |

Woodcert inserts offer a very strong fixing into soft wood, and composite materials. They are installed by screwing them into the parent material using a hexagon driver or allen key. The Type E have no head so they can be screwed under the surface. Common applications include furniture, shopfitting and rotational mouldings. Material & Finishes:-Zamac Zinc Clear (Code 60)Zamac Zinc Yellow (Code 40)

To Specify Use: Series No / Part No / Finish Code (eg 20131 M510 60)

All information is given for guidance only and designers should satisfy themselves as to the suitability of the specification by requesting samples